



**LTO SERIES
ELECTRIC LOW TEMPERATURE OVENS
REPLACEMENT PARTS LIST**

EFFECTIVE SEPTEMBER 12, 2002

BLODGETT OVEN COMPANY, 44 Lakeside Avenue, Burlington, Vermont 05401 USA

Telephone: (802) 860-3700 (800) 331-5842 Fax: (802) 860-3732

www.blodgett.com

Superseding All Previous Parts Lists.

The Company reserves the right to make substitution in the event that items specified are not available.

ERRORS: Descriptive and/or typographic errors are subject to correction.

www.blodgett.com

IMPORTANT: When ordering parts, please provide the model, gas type and serial number of the oven. The identification plate is located on the left side of the combustion compartment and, also, above the control panel under the ledge.

LTO

Revised September 12, 2002

- ☑ ASAP Distributor Required Stocking Parts
- ◆ Doors Are Not Returnable

ELECTRICAL COMPONENTS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	20820	Controller
	20787	Probe
	15726	Relay, Contactor DPDT 120V, 30A
	5281	Terminal Block
	5091	Cord Set Assy
	15381	Flanged Receptacle Assy
	18868	Mode Selector Switch
	4888	Ground Lug
	M0570	Fan, 110 CFM, 4 1/2"
	M0571	Fan Guard
	M0572	Fan, Cord Set
	22040	Element, 120V, 825W
	23225	Clip, For Element
	20837	Motor
	20823	Rocker Switch DPST, Black
	19711	Bulb Holder
	20518	Schematic
	20806	Wiring Label
	20907	Wiring Diagram
	20797	Decal, Cook & Hold LTO-10
	19087	Grommet (protects Control Wires)
	23086	Supressor Assy, RC

EXTERIOR COMPONENTS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	19714	Door Assy, Solid, LH
	21530	Door Assy, Solid, RH
	15554	Door Assy, Solid, LH (Before 1990)
	15553	Door Assy, Solid, RH (Before 1990)
	11629	Trim, Front Side, S/S
	11630	Trim, Front Bottom, S/S
	17997	Body Top, Welded, S/S
	19710	Top Trim Access Panel, S/S
	15404	Top Panel w/Screws
	15383	Handle & Latch Assy
	16490	Latch Strike Assy
	15382	Door Hinges (Set of 2)
	15244	Door Gasket
	15423	Stacking Adapter
	16021	Control Decal (Before 1990)
	16469	BLODGETT Nameplate

INTERIOR COMPONENTS

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	20786	Fan, 4" Blade
	20788	Blower Wheel
	15612	Pan, Maxi
	11638	Rack Support Assy
	10927	Rack, S/S
	15748	Rack Supports (Set of 2)
	15406	Vertical Support Posts
	15407	Thermostat Bulb Guard (Before 1990)
	90105	Drip Pan 2" Deep

ELECTRICAL COMPONENTS

(AFTER 9/81)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	16130	Thermostat, Hold, K-782-24, 80-180 (Before 1990)
	16129	Thermostat, Cook, K-783-24, 100-300 (Before 1990)
	11600	Cord Set Assy, 110-120V (Before 1990)
	11599	Cord Set Assy, 208-240V (Before 1990)
	18298	Axial Cooling Fan (After 7/86)
	19203	Axial Cooling Fan (Before 7/86)
	16030	Control Knob
	16126	Timer, Cook & Hold, 12 Hour
	15403	Terminal Block Assy
	16037	Indicator Light
	11860	Element Assy, 208-240V
	11861	Element Assy, 230-240V

ELECTRICAL COMPONENTS

(BEFORE 9/81)

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	15657	Rotary Power Switch
	11588	Indicator Light Cluster
	15707	Cook & Hold Timer, 12 Hour
	11281	Dial Only for Cook & Hold Timer
	10465	Knob Only for Cook & Hold Timer
	11603	Thermostat, Cook Only, 100-300 F
	15389	Knob Only for Cook Thermostat
	11604	Thermostat, Hold 80-180 F
	15390	Knob Only for Hold Thermostat

STAND & CATERING ACCESSORIES

NOTES

<u>Ref. No.</u>	<u>Part No.</u>	<u>Description</u>
	15761	Dolly Assy, 7" S/S w/Casters
	90103	Dolly Assy, 5 1/2" S/S w/Casters
	15765	Stand, 7"
	15429	Stand, 24" w/Casters
	90104	Stand, 33" w/Casters
	11901	Carrying Handles, Set (Before 1990)
	11902	Rubber Corner Bumpers (Set)