



MODEL 15PDC-A

PRETZEL DISPLAY

MODEL 16PD-A Installation and Operation Instructions

2M-Y4633 Rev. K 1/13/2010











These symbols are intended to alert the user to the presence of important operating and maintenance instructions in the manual accompanying the appliance.

RETAIN THIS MANUAL FOR FUTURE REFERENCE NOTICE

Using any part other than genuine Star factory supplied parts relieves the manufacturer of all liability.

Star reserves the right to change specifications and product design without notice. Such revisions do not entitle the buyer to corresponding changes, improvements, additions or replacements for previously purchased equipment.

Due to periodic changes in designs, methods, procedures, policies and regulations, the specifications contained in this sheet are subject to change without notice. While Star International Holdings Inc., Company exercises good faith efforts to provide information that is accurate, we are not responsible for errors or omissions in information provided or conclusions reached as a result of using the specifications. By using the information provided, the user assumes all risks in connection with such use.

MAINTENANCE AND REPAIRS

Contact your local authorized service agent for service or required maintenance.

Please record the model number, serial number, voltage and purchase date in the area below and have it ready when you call to ensure a faster service.

Authorized Service Agent Listing

Model No.	Reference the listing provided with the unit		
Serial No.	or		
/oltage	for an updated listing go to:		
Purchase Date	Website: E-mail	www.star-mfg.com Service@star-mfg.com	
	Service Help Desk		
	Business Hours:	8:00 am to 4:30 p.m. Central Standard Time	
	Telephone:	(314) 678-6303	
	Fax:	(314) 781-2714	
	E-mail	Parts@star-mfg.com Service@star-mfg.com Warranty@star-mfg.com	
	Website:	www.star-mfg.com	
	Mailing Address:	Star International Holdings Inc., Company 10 Sunnen Drive St. Louis, MO 63143 U.S.A	



CAUTION

This equipment is designed and sold for commercial use only by personnel trained and experienced in its operation and is not sold for consumer use in and around the home nor for use directly by the general public in food service locations. For equipment to be used by the general public, please contact Star Manufacturing, Technical Services.

All shipping containers should be checked for freight damage both visible and concealed. This unit has been tested and carefully packaged to insure delivery of your unit in perfect condition. If equipment is received in damaged condition, either apparent or concealed, a claim must be made with the delivering carrier.

Concealed damage or loss - if damage or loss is not apparent until after equipment is unpacked, a request for inspection of concealed damage must be made with carrier within 15 days. Be certain to retain all contents plus external and internal packaging materials for inspection. The carrier will make an inspection and will supply necessary claim forms.

NOTE: This page contains two models with different design specifications.

GENERAL OPERATING INSTRUCTIONS 15PDC-A

This model requires no electrical hookup.

This pastry display will help impulse sales when placed on either a front or back counter.



Place shelves on rack as shown in this illustration, and place rack into cabinet.

16PD-A

VOLTAGE

This display is equipped for operation on 120V, 60 Hertz AC single phase service only.


Do not connect to any other type of current or the machine will be seriously damaged.

The stainless steel pretzel holder will accommodate up to 36 pretzels and keep them warm with the heat from the two 85 watt reflector flood lamps.

Turn ON the lead-in cord switch to activate both the lamps and the rotation of the pretzel holder.



The doorknob must be attached as shown, with a Phillips screwdriver.



CABINET

CLEANING

For retaining the high luster on the stainless steel, use a non-abrasive standard stainless steel cleaner. Use a damp cloth and warm, mild soap solution to clean the glass and plastic surfaces. The rack and shelf assembly on the 15PDC-A and the holder on the 16PD-A are easily removed and may also be cleaned using a damp cloth and a warm, mild soap solution.

MAINTENANCE AND REPAIRS

Contact the factory, a service representative, or a local service company for service or required maintenance.

Visit our Website at: www.star-mfg.com

Email: <u>service@star-mfg.com</u>

THOROUGHLY INSPECT YOUR UNIT ON ARRIVAL

This unit has been tested for proper operation before leaving our plant to insure delivery of your unit in perfect condition. However, there are instances in which the unit may be damaged in transit. In the event you discover any type of damage to your product upon receipt, you must immediately contact the transportation company who delivered the item to you and initiate your claim with same. If this procedure is not followed, it may affect the warranty status of the unit.

LIMITED EQUIPMENT WARRANTY

All workmanship and material in Star products have a one (1) year limited warranty on parts & labor in the United States and Canada. Such warranty is limited to the original purchaser only and shall be effective from the date the equipment is placed in service. Star's obligation under this warranty is limited to the repair of defects without charge, by the factory authorized service agency or one of its sub-agencies. Models that are considered portable (*see below*) should be taken to the closest Star service agency, transportation prepaid.

- > Star will not assume any responsibility for loss of revenue.
- > On all shipments outside the United States and Canada, see International Warranty.
- * The warranty period for the Ultra-Max, Hot Plates, Griddles, Charbroilers is (3) years parts & labor.
- * The warranty period for the Star-Max, Charbroilers, Griddles, Hot Plates, Fryers & Finishing Oven is (2) years parts & labor.
- * The warranty period for the JetStar six (6) ounce & Super JetStar eight (8) ounce series popcorn machines is two (2) years.
- * The warranty period for the Chrome-Max Griddles is five (5) years on the griddle surface. See detailed warranty provided with unit.
- * The warranty period for Teflon/Dura-Tec coatings is one year under normal use and reasonable care. This warranty does not apply if damage occurs to Teflon/Dura-Tec coatings from improper cleaning, maintenance, use of metallic utensils, or abrasive cleaners, abrasive pads, product identifiers and point-of-sale attachments, or any other non-food object tha comes in continuous contact with the roller coating. This warranty does not apply to the "non-stick" properties of such materials.
- > This warranty does not apply to "Special Products" but to regular catalog items only. Star's warranty on "Special Products" is six (6) months on parts and ninety (90) days on labor.
- > This warranty does not apply to any item that is disassembled or tampered with for any purpose other than repair by a Star Authorized Service Center or the Service Center's sub-agency.
- > This warranty does not apply if damage occurs from improper installation, misuse, wrong voltage, wrong gas or operated contrary to the Installation and Operating instructions.
- > This warranty is not valid on Conveyor Ovens unless a "start-up/check-out" has been performed by a Factory Authorized Technician.

PARTS WARRANTY

Parts that are sold to repair out of warranty equipment are warranted for ninety (90) days. The part only is warranted, the labor to replace the part is NOT warranted.

SERVICES NOT COVERED BY WARRANTY

- 1. Travel time and mileage rendered beyond the 50 mile radius limit
- 2. Mileage and travel time on portable equipment (see below)
- Labor to replace such items that can be replaced easily during a daily cleaning routine, ie; removable kettles on fryers, knobs, grease drawers on griddles, etc.
- 4. Installation of equipment
- 5. Damages due to improper installation
- 6. Damages from abuse or misuse
- 7. Operated contrary to the Operating and Installation Instructions
- 8. Cleaning of equipment
- 9. Seasoning of griddle plates

- 10. Voltage conversions
- 11. Gas conversions
- 12. Pilot light adjustment
- 13. Miscellaneous adjustments
- 14. Thermostat calibration and by-pass adjustment
- 15. Resetting of circuit breakers or safety controls or reset buttons
- 16. Replacement of bulbs
- 17. Replacement of fuses
- 18. Repair of damage created during transit, delivery, & PORTABLE EQUIPMENT installation OR created by acts of God

Star will not honor service bills that include travel time and mileage charges for servicing any products considered "Portable" including items listed below. These products should be taken to the Service Agency for repair:

- * The Model 510FD, 510FF Fryer.
- * The Model 526TOA Toaster Oven.
- * The Model J4R, 4 oz. Popcorn Machine.
- * The Model 518CMA & 526CMA Cheese Melter.
- * The Model 12MC & 15MC & 18MCP Hot Food Merchandisers.
- * The Model 12NCPW & 15NCPW Nacho Chip/Popcorn Warmer.
- * All Hot Dog Equipment except Roller Grills & Drawer Bun Warmers.
- * All Nacho Cheese Warmers except Model 11WLA Series Nacho Cheese Warmer.
- * All Condiment Dispensers except the Model HPD & SPD Series Dispenser.

 * All Specialty Food Warmers except Model 130R, 11RW Series, and 11WSA Series.
- * All QCS/RCS Series Toasters except Model QCS3 & RCS3 Series.
- * All Fast Steamer Models except Direct Connect Series.

- ALL:
- * Pop-Up Toasters
- * Butter Dispensers
- * Pretzel Merchandisers (Model 16PD-A Only)
- * Pastry Display Cabinets
- * Nacho Chip Merchandisers
- * Accessories of any kind
- * Sneeze Guards
- * Pizza Ovens
- (Model PO12 Only)
- * Heat Lamps
- * Pumps-Manual


The foregoing warranty is in lieu of any and all other warranties expressed or implied and constitutes the entire warranty.


FOR ASSISTANCE

Should you need any assistance regarding the Operation or Maintenance of any Star equipment; write, phone, fax or email our Service Department.

In all correspondence mention the Model number and the Serial number of your unit, and the voltage or type of gas you are using.

2M-4497-2 6/1312





MODEL - 16PD-A

SK1535 REV. B 11/3/05

15PDC-A Pastry Display Cabinet MODEL 16PD-A Pretzel Display Cabinet

17	Dout	Number			
Key Number	Part Number	Per Unit	Description and Model Designation		
				15PDC-A	
1 1	2M-Y6654	2 1	SIGN-FRESH DONUT SIGN-PRETZEL	15PDC-A 16PD-A	
	2M-Y4528	1	TOP	IOPD-A	
2 3	C6-Y8239 2U-Y6953	1	MOTOR 120V	16PD-A	
3	2U-Y6954	1	MOTOR 120V MOTOR 240VE	16PD-A	
	2I-H6579	'	GROMMET (not shown)	101 D-A	
4	C6-Y8247	1	TOP LINER		
5		1	HINGE DOOR (SUPPLIED WITH ITEM 25)		
6	2E-Y5921	2	SOCKET-LAMP SPRING 120V	16PD-A	
	2E-Y9433	_	SOCKET-LAMP SPRING 240VE	16PD-A	
7	2S-Y4584	2	LAMP 120V		
	2S-Z0630		LAMP 230CE		
8	C4-Y4616	2	LAMP SHIELD		
9	C5-Y4172	1	MAGNET TAPE		
10	C4-Y8278	3	SHELF-RACK	15PDC-A	
	2A-16007	1	SHAFT ASSEMBLY	16PD-A	
11	C4-15045	1	RACK ASSEMBLY	15PDC-A	
	2B-Z6899	3	HOLDER ASSEMBLY-ELECTROPLATE	16PD-A	
12		3	SOCKET HEAD CAP SCREW (SUPPLIED WITH ITEM 11)		
13	C6-16012	1	BOTTOM PAN-ASSEMBLY		
14	2I-Y7443	6	CHANNEL GLASS (VERTICAL)		
15	2I-Y8169	6	CHANNEL GLASS (HORIZONTAL)		
16	2Q-Y8165	3	GLASS SIDE		
17	C3-Y7377	1	BRACKET HINGE LEFT		
18	C3-Y7446	1	BRACKET HINGE RIGHT		
19	C6-Y7211	1	STRIKE		
20	2R-Z0872	1	KNOB		
04	2C-1492	1	SCREW 8-32 x 1/4	4CDD 4	
21 22	2E-Y6144	1	SWITCH POWER CORD ASSEMBLY 120V	16PD-A 16PD-A	
22	C5-12004	ı		16PD-A	
23	C6-16016 2K-7889	1	POWER CORD ASSEMBLY 240VE BUSHING HEYCO	16PD-A	
24	2I-H7685	4	FOOT	101 D-A	
25	C6-16011	1	DOOR		
26		2	PIN-DRIVE 1/4 X 1" LONG (SUPPLIED WITH ITEM 25)		
27	C4-Y8179	1	BOTTOM		
28	C6-Y6942	2	LAMP CLIP	16PD-A	
29	C6-Y8240	2	CORNER POST		
30	C6-Y8241	1	CORNER POST-WIRE		
31	C6-Y8242	1	CORNER POST-DOOR		
32	C6-Y8245	1	FILLER RIGHT CORNER POST		
33	C6-Y8246	1	FILLER LEFT CORNER POST		
34	2A-Y1110	1	PIN-ROLL		

IMPORTANT: WHEN ORDERING, SPECIFY VOLTAGE OR TYPE GAS DESIRED INCLUDE MODEL AND SERIAL NUMBER

PAGE 1 OF 1

Some items are included for illustrative purposes only and in certain instances may not be available.

